

## INTERPRETING THE NUMBERS: SEMI SYNTHETICS

### BACKGROUND:

This Technical Bulletin is designed to reveal the value of the data generated on routine Used Oil Analysis (UOA) reports and nonroutine reports through a Laboratory Service Request (LSR) for Castrol's Semi Synthetic Metal Working Fluids. The following tests are broken down into two categories: routine and non-routine. Routine tests are those performed on UOA samples. Non-routine tests are those that are used to troubleshoot various system problems. Listed below are concentration control measures:

Total Oil (via Acid Split or via FTIR, %), Alkalinity (%) , and Lube #2 (%)

In an ideal system these concentration controls should be in a 1:1 relationship. For example, if the concentration by alkalinity is 5%, the concentration by total oil should be 5%, etc. The key to interpreting data is to assess the overall trend of the data instead of focusing on individual data points. Proper interpretation requires a comprehensive view of all the data points in relation to one another and the system environment to establish an overall view of the condition of the metalworking fluid.

### ROUTINE TESTS:

#### **Total Oil (%):**

- Total oil by acid split or FTIR is a concentration control that measures the oil content of the sample.
- The oil content functions as a lubricant, corrosion preventive, and a carrier for additives. This test does not distinguish between free oil, emulsified oil, product oil, and non-product oil.
- If the total oil trend is higher than alkalinity, tramp oil is usually present.
- If total oil is rich and trending with alkalinity, water should be added to the system unless the rich total oil trend is caused by tramp oil contamination.
- If the total oil trend is significantly lower than alkalinity, ensure emulsion stability is intact. When total oil is lean and is tracking with alkalinity add product concentrate.
- Tramp oil may be removed with skimmers or coalescer.

#### **Alkalinity (%):**

- Alkalinity is a concentration control that measures the alkaline components of the sample.
- Products are formulated with alkaline raw materials such as amines, that may function as pH buffers, corrosion preventatives, and confer a degree of bioresistance.
- Alkalinity is a reliable measure of a system's concentration as the test results are not affected by contaminations such as dirt, tramp oil, water hardness, and bacteria.
- Alkalinity may be affected by contamination of alkaline products such as cleaners, other coolants, and additions of pH adjusters.
- When the alkalinity percentage is lean, add product concentrate. A lean alkalinity jeopardizes corrosion protection, bioresistance, and machining performance.
- When alkalinity percentage is rich, add water. A rich alkalinity may contribute to the formation of residues, foaming, dermal irritation, and excessive product usage.

***Lube #2 (%):***

- This is a concentration control based on the percentage of Lube #2 as detected by gas chromatography.
- Lube #2 contributes to lubrication in emulsions and is monitored to ensure optimum product performance.
- Concentration of Lube #2 may decrease in trend due to ester hydrolysis or excessive tramp oil may strip Lube #2.
- Lube #2 typically trends slightly lower than alkalinity is UOA.

***Bacteria (cfu/mL):***

- The bacteria test measures the number of bacteria in a system sample after 24 hours of incubation, reported in colony forming units/mL.
- Bacteria may enter a system from the air, water, and contamination and grow rapidly once they inhabit a system.
- Bacteria consume vital product components such as fatty acids and secrete acidic by-products causing a drop in system pH.
- Bacterial contamination can be prevented by maintaining adequate concentration, good filtration, limiting tramp oil and contamination, using quality make-up water, and regular product additions
- A tankside biocide addition of a plant approved biocide may be recommended for bacteria levels  $>10^5$ cfu/mL.

***Dirt 8um (PPM):***

- The dirt test is performed by filtering the sample through an 8um filter patch. The weight of particulate is then reported in parts per million (PPM).
- Dirt levels below 20PPM are acceptable. For precision operations where tolerance and surface finish are critical, maintaining lower dirt levels is critical.
- High dirt levels contribute to decreased tool life, poor surface finish, residues, dermal irritation, and increase the potential for corrosion.
- Various filtration methods are available to help maintain a clean system.
- The addition of a settling agents can be used to help settle fines and swarf and break up smut deposits. Contact Technical Support for assistance.
- This test can also be performed on a non-routine basis at 1um, 3um, 5um, and 20um to establish a particulate size/weight distribution.

***Hardness (gpg):***

- The Hardness test is a measure of calcium and magnesium ions that contribute to hardness in solution.
- Calcium, magnesium, and other minerals come from the water source used for product dilution and vary widely by source and region.
- Over time, these minerals build in a system due to the distillation effect.
- High hardness levels contribute to increased potential for corrosion, residue formation, and fatty acid soap formation.
- Very soft water ( $<2$ gpg) may contribute to foaming with some products. Non silicone defoamers can be added to increase water hardness.

***pH:***

- pH is a measure of how acidic or basic a product is with the scale ranging from 0-14.
- Severe fluctuations in pH are often the result of contamination.
- When foaming occurs, an increase in pH may indicate that the system has been contaminated with an alkaline cleaner.
- Maintaining a proper pH aids in the biostability of the fluid.
- High bacteria levels may contribute to a decrease in pH.

- Low pH can contribute to corrosion on ferrous metals and product instability.
- pH can be increased with product addition or the addition of a pH adjuster

***Refractometer (%):***

- The refractometer reading is a concentration control test based on the degree of light refracted by a fluid when viewed through a prism.
- The refractometer can be severely affected by the presence of dirt, tramp oil, dissolved solids, and other contaminants.
- When the refractometer percentage is lean, the easiest solution is to add product concentrate.
- When refractometer percentage is rich, water should be added to the system.

**NON-ROUTINE TESTS**

***Chloride (PPM):***

- This test measures the level of chloride ions in solution.
- Chloride levels <200ppm are acceptable, however studies have shown that levels >350ppm are extremely detrimental.
- This test can be used to troubleshoot corrosion issues.
- No additives are available to remove chlorides from a system. A full or partial dump-and-recharge may be necessary. Consider adding Synlube L4 for additional corrosion protection.

***CIC (Cast Iron Chip) Rust:***

- This test determines if a coolant sample will cause corrosion of cast iron chips.
- The CIC rust test (or the more severe 50% CIC rust test) is a good indication of the corrosion protection offered by the product and can be used to trouble shoot corrosion issues.
- If rust is exhibited, ensure that the system concentration is adequate.
- If corrosion is exhibited, a good preventive measure is to add SYNLUKE L4

***Dissolved Metals (ppm):***

- This test measures the level of individual metals dissolved in a coolant sample by Inductively Coupled Plasma (ICP) reported as parts per million (PPM)
- The most common reason for metals analysis is to troubleshoot dermal irritation and contamination.
- High levels of dissolved metals can increase the potential for corrosion and contribute to residue and soap formation.